

GIO-176

innoGIO

GIOstar House

Children night projector
with a night light

Product Information

Item Name: GIOstar House – Children night projector with a night light

Item No: GIO-176

Material: ABS+PC+PET+PP+Electronic components

Rated Voltage: 5 V


Rated Current: 1 A

Rated Power: 4 W

Item Size: 119 x 119 x 135.5 mm

Battery Capacity: 1200 mAh

Accessory: Type-C USB Cable



Product Features

1. This product is a warm night lamp, perfect for bed-time.
2. This product is a colourful and captivating projector lamp.
3. This product can play music, which helps create a romantic atmosphere.

How to change the light modes

Light Button

1. Press once to turn on the night light, press again to turn it off.
2. Step-less changes of light intensity: press and hold for two seconds to change the light intensity in a step-less manner, the light brightness will increase from the initial brightness to 100%. Release the button, press and hold for two seconds again, and the light intensity will be reduced from 100% to 30%. The light has a memory function (it memorizes the most recent brightness level).

Projector Button

| | |
|-----------|------------------------|
| 1st Press | Cold White light |
| 2nd Press | Blue light |
| 3rd Press | Warm yellow light |
| 4th Press | Three colour gradients |
| 5th Press | Turn off the light |

(Press and hold for two seconds to turn on the dimming mode of projector light permanently)

Rotation Button


| | |
|-----------|--|
| 1st Press | When the light is on Projector lamp rotates |
| 2nd Press | Projector lamp stops rotating |

Music Button


If you press the music button, the lamp will start playing music. Press the button once to switch to a different song; there are 8 songs in total. Press and hold for 2 seconds to turn off the music. (You do not need to turn on the light to play music).

Instructions for use


1. The product is powered with a 5V=1A charger; do not use an adapter with power over 5V=2A to charge or power the product. (The product is only equipped with a USB cable without an adapter)
2. Fully charge the product before using it. A red light is on during charging, and the green light stays on when the product is fully charged. It takes about 2.5 hours to fully charge the product. The charging time must not exceed 8 hours, otherwise the battery can be damaged, and the product life shortened.
3. Depending on the selected mode of operation, a fully charged product can be used for 2-24 hours.
4. How to use the product:
 - Press and hold the upper cover and turn it counterclockwise to dismantle it from the main body.



- Take off the transparent lampshade, put in the film, then close the transparent lampshade cover.



- Put back the upper cover, press and rotate it clockwise to attach it firmly.



Attention

1. Before use, check the voltage of this product and its compatibility before use.
2. Do not expose the product to direct sunlight. Do not use the product in settings with water mist, humidity, dirt, high temperatures, etc.
3. The product must not be placed into or close to the fire source to avoid fire and explosion hazards.
4. Use it on a flat surface with an angle of no more than 6 degrees to prevent it from falling.
5. Children under the age of 6 years old should not handle the product.
6. When assembling the lampshade, attention should be paid to whether the lampshade is screwed in place, firmly fixed and will not fall off.
7. The light source in the lamp should be replaced by the manufacturer or other agent or person with similar qualifications.
8. The batteries shall be disposed of safely. Obsolete batteries should not be discarded with general waste and instead they should be placed in a special battery recycling bin.

innoGIO



Importer: **INNOGIO** sp. z o.o.
Ostródczka street 74H, 03-289 Warsaw, Poland
www.innogio.com

 @innoGIO.official  @innogio_com