

⚠ WARNING

- Follow the manufacturer's Instructions.
- Do not leave the child unattended.
- To make sure that any harness is correctly fitted.
- Do not use the high chair unless all components are correctly fitted and adjusted.
- To be aware of the risk of open fire and other sources of strong heat, such as electric bar fires, gas fires etc. in the vicinity of the high chair.
- Do not use the highchair until your child has learned to sit up by himself.
- Not to use the high chair if any part is broken, torn or missing.
- Position the high chair away from solid structures and benches to avoid injuries caused by falls and by access to dangerous items.
- Use the high chair on a flat, even and horizontal floor and not to elevate the high chair on any structure or table.
- To reduce the risk of injury, position the high chair away from furniture, walls, hot surface and liquids, window covering cords, and electrical cords and position the high chair away from furniture when the chair is not being used at a table with a tray removed.
- The maximum mass of the child should be 20KGS.
- Prevent serious injury or death from falls or sliding out. Always use the restraint system.
- It is suitable for 6-36month kids.
- Be sure the user familiar with the product instructions, and easy expand and collapse, not use it by force.

1

- The child should be secured in the high chair at all times by the restraining system, either in the reclining or upright position. The tray is not designed to hold the child in the chair. It is recommended that the high chair be used in the upright position only by children capable of sitting upright unassisted.
- Please examine all parts and adjustment method, and be sure the lock instruments locked.
- Do not let baby climb/play or hang in the high chair.
- To avoid danger of suffocation remove plastic cover before using this article. This cover shall be destroyed or kept away from babies and children.


Maintenance Of Common Sense

- Please perform a safety check before use. Check that items such as screws or other small parts inside the chair are securely fastened, that the seat is flexible and that the adjustments are working. In case of irregularities, it is necessary to efficiently repair / maintain the product.
- Clean cushion: cushion should always be clean, in order to avoid contamination affect the health of children.
- Wheels care: regular cleaning wheels, and add oil in axle and suspension position and other activities, to ensure flexibility.
- The chair frame Cleanup: After the course chair with a soft cloth dirty south timely clean it, to avoid affecting the health of children, do not use volatile solvents.
- Clean cloth cover: Remove the cloth cover, with a mild detergent to clean and maintain dry naturally.


2

Parts

1. Chair



2. Detachable tray



3. Front wheels




4. Front axle



5. Universal wheels



6. Brake Handles



3

Description	Baby high chair	Specification	75x58x120 cm
Item No.	GIOmilano	QTY	1 SET
Model No.	GIO-MILANO	Material	Al tube, PP, PU
G.W.	11.3 KGS	Standard	EN14988-2006 +A1-2012
N.W.	9.1 KGS	Available	6-36 monts

innogIO

Importer:

Innogio Sp. z o.o.

Ostródzka street 74H, 03-289 Warsaw, Poland

Tel.: +48 508 311 775 E-mail: innogio@innogio.com




@innogIO.official



@innogio_com


www.innogio.com

Install and use




Warning: Keep baby away when assembly.


- Take the chair from cartons, lift the seat upward by holding the button. (Pls take care with the package bags and others.)
- Hold the two buttons of the leg tubes, to open the chair maximum, then loose the button, to make sure set well.
- Conversely, hold the buttons to collapse the chair to lock.




4



Insert the handles into the leg tubes, and sound „click“, see pics.




The first front wheel: Pull the plug, take the axle out of the front right leg tubes, inset the axle into a front wheel, sound „click“, it is assembled ready. The second front wheel: put the axle with assemble the other wheels, sound „click“, it is ready.




Press the seat height button to low or high seat. Pull the seat and raise it, the seat height can be adjust 7 file.


5




The universal wheels: The wheel rod insert into its holes.




Note: Open it and take out axle.




Press the reset button, plate can be reset.



Pull the grip of the plate below, and Insert the both tubes into the hole of the handles, then loose the grip to bottom, assemble ready. Conversely, disassemble.




Hold the back bar, then pull forward or backward, it can adjust the back angle with 5 position.




Press the footrest button, it can be 3-position. Push the footrest upward directly, and press button when down-adjust.


6



The tray can not be removed in case baby hands hurt, take it out and put away on the ears of legs.




Press the red button to release brake, hold it forward, then loose it to brake.



Tie seat belts to segregator till sound „click“; Untie the belt, press the center of button, the both belts pop-up.

GIO-MILANO

innoGIO



GIO milano

MULTIFUNCTIONAL BABY HIGHCHAIR

DIRECTIONS FOR USE

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE