Scannen Sie den OR-Code, um das Handbuch herunterzuladen.

Scannez le code QR pour télécharger le manuel Escanee el código OR para descargar el manual

Digitalize o código OR para descarregar o manual

Scansiona il codice QR per scaricare il manuale

Scan de QR-code om de handleiding te downloaden

Скануйте OR-код, щоб завантажити інструкцію

Naskenujte QR kód a stáhněte si návod k použití

Naskenujte QR kód a stiahnite si príručku

Scanează codul OR pentru a descărca manualul

Nuskaitykite OR koda, kad atsisiustumėte instrukcija Nolasiet QR kodu, lai lejupielādētu rokasgrāmatu

Lae juhend alla, skannides QR-koodi

A kézikönyv letöltéséhez olvassa be a OR-kódot.

لىلدلا لىزنتل ةعيرسلا قباجتسالا زمرحسما



ìnnoGIO

INNOGIO sp. z o.o. ul. Ostródzka 74H, 03-289 Warsaw, Poland www.innogio.pl








GIO-759BY

ìnnoGIO



GlOperfect Vibes Beauty LED mirror

USER MANUAL

PRECAUTIONS

Please read this manual carefully before use.

- This product is intended for indoor use only. Do not use it outdoors.
- This product is not a toy and is not intended for children.
- 3. Install the device on a wall. Place the product in a safe location that is not exposed to mechanical damage.
- 4. Plug the USB cable into a USB port or adapter. Note that the power adapter is not included. Ensure that the USB port or adapter outputs 5V/2A. Avoid devices with voltages higher than 5V to prevent overheating, damage to the light strip, and safety hazards.
- 5. If you choose to use adhesive hooks on a smooth wall, make sure the hooks have been fixed for at least two hours before hanging the LED neon mirror.

SPECIFICATIONS

Product name: GIOperfect LED mirror Vibes Beauty

- Cosmetic mirror with LED neon-style lighting

ID: **GIO-759BY**

Color: white & pink

Material: PP

Power output: 5V/2A

Interface: **USB-C** (power adapter not included)

INSTALLATION METHOD

Install the mirror on the wall

(the screws are not included)









Hang on a wall screw



Hang with a hook

- Before each start-up, check the device for damage. Unwind the power cord when turning on the device to avoid overheating.
- Disconnect the device from the power supply before leaving home.
- Disconnect the power before cleaning and wipe with a soft, dry cloth. Avoid using liquid cleaners.
- 4. The LED elements are non-replaceable. Attempting to repair the device yourself or interfering with its structure may result in electric shock.
- 5. The product is subject to separate collection in accordance with the WEEE Directive.

FRIENDLY REMINDER

This product is for decorative lighting only. Do not allow children to operate it alone. If you notice abnormal heating, smoking, or other anomalies, disconnect the power immediately and contact a professional for assistance.